

Product info

Ventilating system COLT/VENTO

CH-5036 Oberentfelden Switzerland +41 62 737 72 80 www.pedi.ch

Pedi AG

Koellikerstrasse 17

Rev. 5

Page 1 / 4

9501

## Ventilating system COLT/VENTO for protective suits

The ventilating system COLT / VENTO is used for the ventilation of protective suits. It is worn inside the suit and protected against contamination. As the device is separated from the suit and fully re-usable, only the empty suit film has to be disposed.

The highly reliable, maintenance-free and always ready-to-use ventilating system consists of the two components COLT and VENTO:

## COLT:

The belt system is used for strain relief and connection of the breathing air supply hose.

Variant PUR:Breathing air supplyVariant VARIO:with air volume flow controlVariant COOL:with continuous cooling of breathing airVariant KLIMA:with stepless cooling / heating of breathing air

- sound-damped and diffused exhaust air
- antistatic air supply hose according to EN 139, with ID 12mm
- with connection coupling for VENTO
- with textile straps and pouch, washable at 40°C
- individual test with test report
- permissible operating pressure: max. 10 bar

## VENTO:

Lightweight and comfortable vest made of breathable fabric, adjustable with Velcro straps, ideal for personal delivery to operators.

- with efficient and quiet air distribution system for head, arms and legs
- with acoustic signal as a warning when the minimum air volume flow is not reached
- one-size-fits-all sports vest in one size
- vest with name tag (Velcro)
- washable at 40° C

## Available versions:

-

Pedi AG	Product info: Ventilating system CO		
PI-04404	Rev. 5	Page 2 / 4	

The **COLT belt system** acts as a strain discharge and is worn inside and separated from the suit. Thus, the operator is not limited concerning his movements and the device is protected against any contamination.

The COLT versions differ in the following details:



COLT-PUR:

Strain discharge and breathing air supply, with belt and case. 500 g (without Pedi Safety coupling) Weight: 790 g (with Pedi Safety coupling)





COLT-VARIO: Continuously variable flow control, with belt and knob

> **COLT-COOL:** Continuous cooling of the breathing air with knob and exhaust hose with silencer. Weight: 1100 g (without Pedi Safety coupling)

1390 g (with Pedi Safety coupling)

**COLT-KLIMA:** Stepless cooling / heating with knob and exhaust hose with silencer. Weight:1200 g (without Pedi Safety coupling) 1490 g (with Pedi Safety coupling)



Pedi AG	Product info: Ventilating system COLT/VENTO		
PI-04404	Rev. 5	Page 3 / 4	

For a volume flow rate of 250 l/min, the COLT/VENTO systems require the following supply pressures:

Device	Volume flow effectively [l/min]	Pressure [bar]	Temperature difference ∆T [° C]
COLT-PUR	250	0.9	
COLT-VARIO Regulator closed	406	5.3	
COLT-VARIO Regulator open	585	5.3	
COLT-COOL Cooling active	250	3.5	-12
COLT-COOL Cooling inactive	250	3.0	0
COLT-KLIMA Setting cold	250	4.9	-15
COLT-KLIMA Setting warm	250	5.1	+15

The lightweight **VENTO** air distribution vest is also worn inside and separated from the suit. It can be washed and reused.



By means of Velcro on the front the vest can be adjusted to any size. Weight: 1510 g

The efficient and quiet air distribution system is equipped with a noise reducer and offers the following ventilation lines:

- 2 ball hoses for the hood area, individually adjustable, no direct streaming of the eyes, no fogging of the disc,
- 2 tubes each for the hands and feet, fixation by means of elastic stripes,
- Acoustic warning signal when the flow rate falls below the minimum air volume flow,
- the whole unit is easily to remove and reassemble in case of washing.



Pedi AG
PI-04404

Rev. 5

Page 4 / 4



A complete set of COLT/VENTO ventilating system can be stored in the bag.